




Point number	Grid Northing	Grid Easting	Elevation	Code
100	13816097	2238592	751.11	FH

Unit 3
FH 100

Point number	Grid Northing	Grid Easting	Elevation	Code
104	13816092	2239009	766.375	FH

FH 42335

FH 42333

Point number	Grid Northing	Grid Easting	Elevation	Code
102	13816233	2239370	765.297	FH

FH 42317

Point number	Grid Northing	Grid Easting	Elevation	Code
101	13815817	2238527	768.26	FH

FH 42339

Point number	Grid Northing	Grid Easting	Elevation	Code
103	13815777	2238957	781.47	FH

FH 42334

FH 42336

Point number	Grid Northing	Grid Easting	Elevation	Code
105	13815874	2239412	776.681	FH

FH 42309

Point number	Grid Northing	Grid Easting	Elevation	Code
100	13815525	2238525	786.41	FH

FH 42338

FH 42325

FH 42308

Point number	Grid Northing	Grid Easting	Elevation	Code
101	13815461	2239016	782.39	FH

FH 42332

Point number	Grid Northing	Grid Easting	Elevation	Code
106	13815533	2239258	776.644	FH

FH 42337

FH 42331

Point number	Grid Northing	Grid Easting	Elevation	Code
100	13815379	2239339	770.65	FH

FH 42295